


FLOATING CORNER SHELF INSTALLATION




1 Shelf Location

Hold the shelf up in the corner of the shower at the desired height and mark the corner of the shower wall, just above the corner shelf.

The water channels should face up.


Recommended Shelf Height



The most common height for the floating corner shelf is between chest and eye height of the user.

2 Drilling Holes

From the mark on the wall made in step #1, measure down about 3/4" and use the mounting bracket to mark the holes. Drill a 1/4" clearance hole through the shower wall panel. For the corner screw, there will be wood backing in the wall. For the screws at the ends of the bracket, use the plastic anchors.




Always drill a clearance hole through the Onyx wall panel and never fasten directly into the Onyx material.

Make sure the bracket is level when marking the holes.

3 Attaching the Bracket

Attach the bracket to the studs in the walls using the 2 1/2" screws. Tighten just enough so that the bracket is snug in the corner - be careful not to over-tighten.

Dry fit the caddy to insure tight fit and level installation.




If the screw is not able to hit a stud. Use the plastic anchors in the hardware bag.

4 Mounting the Shelf

Apply Onyx Adhesive silicone to the back of the shelf. A small bead of silicone per side is sufficient. Apply the adhesive silicone slightly away from the outside edge so that it will not press out when the shelf is installed.

Hang the shelf on the bracket and gently slide it into the corner against the two walls.




Leave a gap between the finished edge of the shelf and the adhesive silicone. This will prevent the silicone from squeezing out when the shelf is pressed against the wall.

5 Securing & Sealing

After the shelf is installed, secure it in place with masking tape until the adhesive silicone starts to cure (usually 15 minutes to an hour).

Remove the tape and apply the Color Matched Seamfill to the edges of the shelf.



To smooth out a seamfill bead with your finger, dampen a paper towel with rubbing alcohol and then dampen your finger. Next, run your finger along the bead of seamfill, wiping any excess silicone onto the paper towel.

The rubbing alcohol will keep the silicone from smearing.